


# TWINLED F1

## INSTALLATION INSTRUCTIONS

TYPE:

PROJECT NAME:




Driver: 120V Remote Driver

### Installation Instructions

1. Insert fixture into ground with spike
2. Orient light source (A) as desired
3. Connect wire to driver. Below are two wiring options

### WIRING DIAGRAM

OPTION 1:



OPTION 2:

